

ASSEMBLY INSTRUCTIONS

OVEN CABINET (OC332484, OC332496)


CABINET PARTS LIST

**A-Doors & Face Frame B-End Panels(2) D-Top/Medium/Bottom Panels(3)
E-Back Panel H-Toe Kick**


HARDWARE PARTS LIST

None


STEP1




STEP2



STEP3



STEP4



STEP6

STEP5

