

# ASSEMBLY INSTRUCTIONS

## WALL CABINET (W2430, W2730, W3030, W3330) (~~W3630, W3930, W4230, W4830~~) (~~W2724, W3024, W3324, W3624~~) (~~W332434, W362424~~)

### CABINET PARTS LIST

**A-Doors & Face Frame   B-End Panels(2)   C-Shelves(2)   D-Bottom Panel & D-Top Panel  
E-Back Panel**

### HARDWARE PARTS LIST

**1. Shelf Clips (8)   2. Screws (Ø3.5\*25) 6 OR 8**

